

Instrument RadioStack™

USER MANUAL
(MEC2.520-8AUG08)

**Please read this manual before operating your
units and keep it for future reference**

VRinsight

Virtual Reality Insight

All stated here is subject to change without advanced notice for improvement.

Tel : +82-31-284-7090~91 Fax : +82-31-284-7092 E-mail : info@vrinsight.com Web site : www.vrinsight.com

BEFORE USE : Thanks for purchasing VRi's Radio Stack.

Before operating your units, please read through this manual and keep it for future reference. For any further question, visit VRi's web-site (www.vrinsight.com) or contact as below;

Tel : +82-31-284-7090 (7091)

Fax : +82-31-284-7092

E-mail (Support team) : tech@vrinsight.com

NOTE : This manual could be redistributed unless as long as you do not modify the contents. This manual has been written out on an Instrument RadioStack panel basis.

All software (& software versions) stated here (MEA2.520-8AUG08) is subject to change without advanced notice for improvement.

If you want to download the latest driver version for panel & application programs, visit <http://vrinsight.com>

Radio Stack picture



**Instrument RadioStack
after attaching Keyskin**



**Instrument RadioStack
with rack**

Features

- Same functionality and externality with real Radio Stack
- Adopting red color 7-segments and tact switches getting close to realistic
- Adopting luminous tact switches confirms the engagement
- Integrated unit with all radio stack units; COM1/2, NAV1/2, ADF, DME, TRANSPONDER, AUTO-PILOT unit
- Realistic concentric radio knobs
- All metal cases (Metal rack included)
- One year warranty

Technical specifications

- USB interface type to computer
- External power requirement : DC 5V adaptor
- 22cm (L) * 31cm (W)
- 2.5Kg (with rack)

Operating software

- SerialFP2

Compatibility software

- Flight simulator 2004 / FSX by Microsoft

SerialFP2 Installation

With Instrument RadioStack, an “Install CD” is included. When you insert it in CD driver of your computer, “*VRinsight HTML*” document will be shown. Then click “SerialFP2” (operating software) and install it at a proper folder.

“SerialFP2” is the main operating software of VRinsight used for MCP combo panel, CDU panel and Instrument RadioStack panel.

SerialFP2 software supports all functions of Instrument RadioStack and completely interfaced with MSFS9 and MSFSX enables full simulation with simple connection your computer through USB. Be sure that when installing SerialFP2, “Install USB-Serial Driver” must be checked.

After installation, you can find “SerialFP2” in “All programs” of “Start menu”.

USB Connection

The connection between Instrument RadioStack and your computer is made using a USB cable that plugs into one USB port on your computer. **If you want to use a USB hub, be sure that the USB hub must compliant with USB 2.0 standard. Otherwise it may cause a malfunction.**

When you connect Instrument RadioStack to your computer at first, your computer will detect it and will describe the process step by step.

Power Connection

Power supplying of Instrument RadioStack is done by universal power supply adaptor DC 5V (Included in package). Make sure that before trying to operate Instrument RadioStack, you must connect the universal power supply adaptor first in order to prevent malfunction.

Before trying to operate, be sure that all 7-segments are lighting up.

Run “SerialFP2”

When you confirm all setup processes done; “SerialFP2” installation, “USB connection” and “Power connection”, you are ready to operate Instrument RadioStack.

Download & install “FSUIPC”

Refer to “Download & install FSUIPC” at “Download”

Double click shortcut of “SerialFP2” or find it in “All programs” of “Start menu .
If everything is done properly below window will be shown.



Drop down “Select Aircraft” to select “Radios for MSFS2004/FSX with FSUIPC” and press “Load FS Module” button.

*** To operate Instrument RadioStack panel, MSFS9 / MSFSX must be run before run SerialFP2.**

Controls for each part



COM Unit : 2 rotary switches, 2 luminous tact switches. COM1 / COM2 with 5 digit / 7-segments displaying communication frequency with ATC



Engages COM1 / COM2



Pushing : Blinks the frequency(MHz : 1MHz unit) / the frequency (KHz : 25KHz unit) to change
Rotating : Changes the frequency



Displays the frequency information



NAV Unit : 2 rotary switches, 4 luminous tact switches. NAV1 / NAV2 with 5 digit / 7-segments displaying Active and Standby frequency of NAVAID (VOR, VORTAC, DME, ILS)



Engages NAV1 / NAV2



Swaps the standby frequency for active frequency .



Pushing once : Blinks the frequency (KHz : 50KHz unit) to change

Pushing twice : Blinks the frequency (MHz : 1MHz unit) to change

Pushing third : Display the bearing between airplane and VOR (OBS)

Rotating : Changes the frequency



Displays active frequency and standby frequency .

Displays the bearing between airplane and VOR



ADF Unit : 1 rotary switch, 1 luminous tact switch. 3 digit / 7-segments displaying ADF frequency



Engages ADF



Pushing : Blinks ADF frequency to change

Rotating : Changes the frequency



Displays the ADF frequency




DME Unit : 2 luminous tact switches. 3 digit / 7-segments and 4 Digit / 7-segments displaying the speed of the airplane and the distance between airplane and VOR



Engages DME1 / DME2



Displays the speed of the airplane and the distance between airplane and VOR



Transponder Unit : 8 tact switches, 4 luminous tact switches. 4 Digit / 7-segments displaying transponder code



Sets SQ to VFR. Use it to change squawk code.



Sends "IDENT" signal of the airplane to the ATC



Sets transponder mode to "NORM"



Sets transponder mode to "STBY"



Inputs Transponder code



Displays Transponder code



Autopilot Unit : 8 luminous tact switches

- AP** Engages A/P mode
- HDG** Engages HDG mode
- NAV** Engages NAV mode
- APR** Engages APR mode
- BC** Engages Back-course mode
- ALT** Engages ALT mode
- THR** Engages Auto-Throttle
- FD** Engages Flight Director(F/D)